

Acer LCD Monitor Quick Start Guide (QSG)

Important safety instructions

Please read the following instructions carefully.

1. To clean the LCD monitor screen:
 - Turn off the LCD monitor and unplug the power cord.
 - Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
2. Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage it.
3. Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.
4. Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature.
5. Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to 140° F). Storing the LCD monitor outside this range may result in permanent damage.
6. Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:
 - Monitor-to-PC signal cable is frayed or damaged.
 - Liquid spills onto the LCD monitor or the monitor is exposed to rain.
 - The LCD monitor or case is damaged.

Attaching the monitor to the base


1. Remove the monitor from the packaging.
2. Attach the footstand to the base. (for selected models).
3. Turn clockwise to lock. Ensure that the base is locked onto the stand. (for selected models)
4. Secure the base to the stand by turning the screw using the intergrated tab or a suitable coin. (for selected models)

Connecting your monitor to a computer

1. Turn off your computer and unplug your computer's power cord.
2. Connect the signal cable to the DP (optional) and/or HDMI (optional) input socket of the monitor, and the DP(optional) and/or HDMI (optional) output socket of the graphics card on the computer.
3. Connect the USB Cable(Optional)
Connect the USB cable to port for fast charge.
Connect the USB cable to port.
4. Insert the monitor power cable into the power port at the back of the monitor.
5. Connect the power adapter and power cord to the monitor, then to a properly grounded AC outlet.




Note: Audio output is only for audio output model. Please check user manual for more instruction.







G-SYNC :

G-SYNC requires an NVIDIA GeForce GTX 1070 BOOST GPU or higher. For more information, visit the nVidia® website: <http://www.nvidia.com/page/home.html>



External controls

1	Power button	Turns the monitor on/off. Blue indicates power on. Amber indicates standby/ power saving mode.
2	Function key 	a. Press to view Main page. Press again to enter hotkey1 function. b. When the Function Menu is active, press this key to view the basic information for your monitor and current input or reset the custom color settings to the factory defaults.
3	Function key 	a. Press to view Main page. Press again to enter hotkey2 function. b. When the Function Menu is active, press this button to select scene scenario mode or game mode .
4	Function key 	a. Press to view Main page. Press again to enter Input select function. b. When the Function Menu is active, this button will quit the OSD.
5	Function key 	a. Press to view Main page. Press again to enter next function in the Function Menu. b. The single toggle button on the backside of the Display bezel operates like a joystick. To move the cursor, simply toggle the button in four directions. Press the button to select desired option.

Note: Acer monitor is purposed for video and visual display of information obtained from electronic devices.

Regulations and safety notices

FCC notices

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

CE declaration of conformity

Hereby, Acer Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of Radio Equipment Directive (2014/53/EU) and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of eco design requirements for energy-related product.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with EMC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.

In order to prevent damage to the monitor, do not lift the monitor by its base.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

CAN ICES-3(B)/NMB-3(B)

Disposal of waste equipment by user in private household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

SPECIFICATION

LCD Panel	Driving system	TFT Color LCD	
	Size	24.5"W (62cm)	
	Pixel pitch	0.28mm(H) x 0.28mm(V)	
	Brightness	Native 400nits, HDR400 mode: peak 400nits	
	Contrast	1000:1 (Native)	
	Viewable angle	178° (H) 178° (V) (CR≥10) (Typical)	
	Response time	1ms (G to G) 0.3ms (G to G) min	
	Panel Type	In-Plane Switching	
	H-Frequency	HDMI(2.0):30~291KHz DP(1.4):30~466KHz	
V-Frequency	HDMI(2.0):24~240Hz DP(1.4):24~360Hz		
Display Colors	16.7M Colors		
Dot Clock	600MHz		
Max. Resolution	Normal mode: HDMI: 1920x1080 @240Hz DP: 1920x1080 @360Hz		
Plug & Play	VESA DDCCI/DDC2B		
Power consumption	ON Mode	37W	
	Standby Mode	0.5W	
	Off Mode	0.3W	
Input Connector	DP (Only DP Model)(Optional) HDMI (Only HDMI Model) USB Hub / USB3.0 x 3, USB2.0 x 1(Only USB Hub Model) USB-B (Only USB-B Model)		
Input Video Signal	DP (Only DP Model)(Optional) HDMI signal (Only HDMI-Input Model) USB (Only USB Model)		
Speakers	2W x 2		
Audio	Audio-Output (Only Audio-Output Model)		
Maximum Screen Size	Horizontal:543mm Vertical:302mm		
Power Source	100-240V~, 50/60Hz		
Environmental Considerations	Operating Temp: 0° to 40°C Storage Temp: -20° to 60°C Operating Humidity: 20% to 80%		
Dimensions	557(W) x 411~507(H) x 236 (D)mm		
Weight (N. W.)	5.88kg Unit (net)		
Mechanism spec	Tilt: -5° to 25° Swivel: +/-20° Height adjustment: 115mm Pivot: Yes Detachable foot stand: Yes		
External Controls:	Functions	Peak white (nits) Contrast Blue Light Dark Boost Backlight Response SDR/HDR Variable Backlight Auto Brightness Max Brightness Relative Gamma Color Temp. ColorSense DP YCbCr sRGB HDMI YCbCr sRGB 6-axis color Volume G-SYNC Esports NVIDIA Reflex Latency Analyzer NVIDIA ULMB Over Drive	Refresh Rate Num Aim Point Language OSD Timeout Transparency OSD Lock Auto Switch Input Input Lighting Hot Key Assignment ProxiSense Rest Reminder Deep Sleep Quick Start Mode Power-off USB Charge Reset
* Specifications may vary depending on model, sku and/or region.			

Find manuals and other documents for your Acer product on the official Acer support website.