



Statement of Volatility - Dell UltraSharp U3417W Monitor

△ CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

The purpose of this document is to certify that the Dell UltraSharp U3417W monitor will not save, retain, or reproduce a signal to any internal or external component after power has been removed and reapplied to the unit.

The Dell UltraSharp U3417W monitor contains both volatile and non-volatile (NV) memory ICs. Volatile memory(s) lose their data immediately upon removal of power. Non-volatile memory ICs continue to retain their data even after the power has been removed. However, no input video data is written into these memory ICs during operation.

List below contains volatile and non volatile memory ICs used in the Dell UltraSharp U3417W monitor.

| | |
|---|---|
| System EEPROM | ST M24C16 |
| Size | 16Kbit |
| Type [e.g. Flash PROM, EEPROM] | EEPROM |
| Volatility | Non-volatile |
| Can user programs or operating system write data to it during normal operation? | OSD setting: Yes |
| Purpose | Storage of system setting (OSD) |
| How is data input to this memory? | Control the OSD menu and change OSD setting(ex. Brightness, contrast, color setting) and the setting will be stored into system EEPROM. |
| How is this memory write protected? | Software write protected |

| | |
|---|---|
| HDMI EDID EEPROM | ROHM BR24G02 |
| Size | 2Kbit |
| Type [e.g. Flash PROM, EEPROM] | EEPROM |
| Volatility | Non-volatile |
| Can user programs or operating system write data to it during normal operation? | No |
| Purpose | Storage of HDMI EDID |
| How is data input to this memory? | HDMI EDID is embedded in the firmware, and copied to EEPROM after F/W programming. (or via customized EDID tool) |
| How is this memory write protected? | Hardware and software write protected |

| | |
|---|--|
| Flash ROM | WINBOND W25Q32FVSSIG |
| Size | 32Mbit |
| Type [e.g. Flash PROM, EEPROM] | Serial flash memory |
| Volatility | Non-volatile |
| Can user programs or operating system write data to it during normal operation? | No |
| Purpose | To store firmware |
| How is data input to this memory? | Loading flash memory requires a vendor-provided tool and firmware. |
| How is this memory write protected? | Software write protected |

△ CAUTION: All other components on the system board lose data if power is removed from the system. Primary power loss (unplugging the power cord) destroys all user data.